

6-8 OCTOBER 2021

EXHIBITION TECHNICAL REGULATIONS

1) PRELIMINARY NOTE

In this text the term "BolognaFiere" or "Organiser" will be used to indicate Fiere Internazionali di Bologna S.p.A.

2) SPECIAL REGULATIONS

2.A - Dates, time and venue of the Exhibition

The Exhibition will be held from 6 to 8 October in the Bologna Exhibition Centre with the following opening time:

- 6-7-8 October 2021: 9.00 a.m. till 6.00 p.m.

Exhibitors may enter the exhibition halls:

- on October 6 from 8.00 a.m. to 6.30 p.m.
- on October 7 from 8.30 a.m. to 6.30 p.m.
- on October 8 from 8.30 a.m. to 9 p.m.

The Fair is open only to professionals.

2.B - Availability of stands: hand-over

Unfurnished areas will be available to Exhibitors from October 2, 8 a.m. and will have to be completed within 7 p.m. of October 4, 2021.

Exhibitors shall ensure that their stand builder undertakes to respect the above mentioned deadline by including a special clause in the contract.

Pre-equipped booths will be available on October 5 from 8.00 a.m.

It should be noted that Exhibitors and Stand Builders have to enter the Fairgrounds by the Maserati-Calzoni Goods and Vehicles Entrance, located in Via Maserati.

2.C - Access to the Exhibition Centre during the stand furnishing period

During the pre-fair and post-fair times, Exhibitors may enter the Bologna Exhibition Centre only if their personal data have been registered on the website PASS (Ex Gate BolognaFiere): <https://pass.bolognafiere.it>, which can be reached by the link available in the Exhibitors Reserved Area (www.accadueo.com). Exhibitors and their fitters/suppliers who do not register on this site and do not print the entrance passes will not be authorised to enter the Exhibition Centre during the exhibition set-up and dismantling periods.

REGISTRATION IN THE PORTAL "PASS" (EX GATE) TO ENTER THE FAIRGROUNDS DURING SET UP AND DISMANTLING PERIODS.

Each Exhibitor will be sent (to the administrative email address specified in the application form for the exhibition) a password and an Id User Code to access his reserved area on the exhibition website, in which he must enter the information regarding his company's personnel and vehicles in order to print his entrance passes. The procedure also requires the Exhibitor to perform the Work Assignment operation with regard to his stand fitters and suppliers. The Work Assignment procedure will allow these companies to receive a password so that they may register their employees and vehicles in their reserved area, and print their entrance passes.

Suppliers/carriers entering the Exhibition Centre to deliver materials on behalf of Exhibitors must also be in possession of the Packing List bearing the identifying data of the Exhibitor receiving such materials (Exhibitor's name, hall, stand). Suppliers who present a Packing List without such data will be denied entrance to the Exhibition Centre.

As required by current laws regarding health and safety at the workplace, the Exhibitor (customer), in relation to the works to be assigned, is responsible for verifying possession of the technical-professional characteristics of all main contractors, of all subcontractors, and of all self-employed individuals that will work for the Exhibitor in the Exhibition Centre.

IN THE "PASS" WEBSITE THERE WILL ALSO BE PUBLISHED THE NECESSARY

INFORMATION INCLUDED IN THE SAFETY UNIQUE DOCUMENT, Dlgs 81/08 and subsequent modifications, to enter the Fairgrounds.

During the stand furnishing period stand builders and vehicles may enter the Exhibition Centre at the following times:

- 2-3-4 October: from 8.00 a.m. until 6.00 p.m. (unfurnished areas only)

Stand fitters already inside the Exhibition Centre may continue to work until 7.00 p.m.

On October 5, the day before the beginning of the Exhibition, from 8.00 a.m. to 7.00 p.m. no booth setting up can be carried out; therefore only sampling operations, graphics arrangements, or other similar activities exclusively using manual tools, will be allowed.

In these days the access to the Fairgrounds is only allowed presenting the personal Pass and wearing the Personal Safety Devices. Access to the exhibition halls is forbidden to all kinds of NON-ELECTRIC vehicles.

In order to allow smooth operation during the mounting phase of the trade fair, exhibiting companies are requested to provide the technical data relating to particular large and/or heavy goods (that require the use of particular means of handling like crane truck) which they intend to exhibit inside the stand. Waiting in the proximity of the exhibition halls must be limited to the time strictly required to load and unload goods and equipment. Vehicles that are not used for these operations must be parked in the designated areas. In particular unloading and temporarily parking of containers or detachable parts of non self-moving vehicles are not allowed.

In accordance with work safety legislation, BolognaFiere S.p.A. may establish specific criteria for admission to the exhibition centre during the stand set-up work and may restrict vehicle access and/or establish charges in the event vehicles are parked outside the spaces or for longer than the timeframes established by BolognaFiere S.p.A.

In particular, if cars or other vehicles remain in the exhibition centre for more than two hours, the exhibitor whose password has been used to register the vehicle will be charged a sum of € 500.00 plus VAT.

It is furthermore prohibited to leave any kind of vehicle inside the Exhibition Centre during closing times.

Should this occur, Bolognafiere S.p.A. will provide for the forced removal of the vehicle itself outside the Fairgrounds at the owner's own risk and expenses.

For safety reasons, Exhibitors and stand fitters working on their behalf are not allowed to use their own forklifts, mobile cranes, aerial platforms etc. inside the Exhibition Centre; for this particular need, they must contact BolognaFiere, to ensure strict compliance with safety regulations.

The above mentioned rules do not apply to vehicles equipped with on-board crane arm, which may be used inside the halls only if equipped with appropriate pipes discharging motor exhausts outside the Halls.

If any lifting equipment (belonging to Exhibitors or their suppliers) is brought in and used without prior authorization, BolognaFiere S.p.A. will immediately stop its use and order its removal from the Exhibition Centre at the owner's risk and his/her own expenses.

2.D - Removal of products at the end of the exhibition and leave of the booths

Exhibition samples may be removed from the Exhibition Centre at the following times:

- October 8 from 6.00 p.m. till 9.00 p.m. (only for removal of exhibited products by trolleys)
- Dismantling and delivery of pre-fitted stands

Stands may be dismantled and removed from the Exhibition Centre at the following times:

- **October 9-10: from 8.00 a.m. till 6.00 p.m.**

Stand fitters and exhibitors already inside the Exhibition Centre may continue to work till 7.00 p.m.

Vehicle access to the outdoor areas and halls will be governed by the provisions covering stand furnishing (see art. 2.C).

Clearance of all stands, regardless of their location, must be completed by 7.00 p.m. on October 10.

In default, this will be done by BolognaFiere S.p.A. and the Exhibitor will be required to reimburse all direct and indirect costs incurred for removal (The sum is actually of € 300.00 for each surface of 16 sqm and subject to any reimbursements for further damages).

The Exhibitor shall be solely liable for any damage or theft that may occur during the exhibition as well as in the setting phases prior and after the exhibition.

It should be noted that Exhibitors and Stand Builders have to enter the Fairgrounds by the Goods and Vehicles Entrance "Maserati-Calzoni" located in Via Maserati.

2.E - TERMS OF PAYMENT

Payment of the fees due for participation in the Exhibition shall be made either directly or in the manner set down on the application form.

Although the "exit voucher" may not be issued to Exhibitors who have not settled all their dues either directly or indirectly, it does not constitute a receipt of payment of the sums due for participation in the Exhibition and shall be valid only for the vehicle specified thereon.

2.F - INSURANCE, EXEMPTION AND ASSUMPTION OF RESPONSIBILITY

During the hall opening times the Exhibitor shall watch over his own stand either directly or by means of his personnel. Although BolognaFiere S.p.A. provides a general day and night security service inside the Exhibition Centre when the Centre is closed to the public and exhibitors for the entire duration of the Exhibition and during the stand installation and dismantling periods, it is hereby released from any and all responsibility in respect of theft and/or damage that may be sustained by the Exhibitor.

The Exhibitor shall also be responsible to BolognaFiere S.p.A. for all direct and consequential damage which for any reason is attributable to him or to the personnel working for him (including damage caused by the furnishings or by the systems set up either by the Exhibitor or by third parties hired to do so, even if they have been inspected by BolognaFiere S.p.A.).

Compensation for damages deriving from such theft or damage as may be sustained by the Exhibitor, even outside the hall opening hours (including all the days set aside for stand installation and removal) shall be made solely by means of adequate insurance policies.

The Exhibitor shall benefit from the following insurance policies taken out by BolognaFiere S.p.A.:

- All Risks cover (including fire and theft) against direct and material damage to stand fittings, furnishings, equipment and goods in the stand, excluding cash, items of value, other valuables and similar and excluding software installed on computers and excluding damages from non-use of stand fittings, furnishings, equipment and goods during the exhibition - € 40,000.00 full first loss (including fire and theft) cover with full excess of € 300.00 for each item of damage, increased to € 600.00 for damages occurring after the end of the exhibition.
- Third Party Liability cover, comprising the damages from fire: single limit € 50,000,000.00;
- Third Party Liability cover for employees: limit € 3,000,000.00 per claim with limit of € 2,000,000.00 per person.
- the Insurance Company shall waive all claims towards Exhibitors and BolognaFiere S.p.A.

The aforesaid insurance covers are governed by the conditions and limitations which the Exhibitor may request from the exhibition Organising Office and which are printed in the documentation for the exhibition.

These insurance policies do not release the Exhibitor from liability in respect of all risks which, according to the independent assessment of the Exhibitor, are not covered or exceed the limits of cover as set out above. The Exhibitor shall take out such supplementary cover as he deems appropriate.

In particular, given the existence of a video surveillance system, in case of theft, a report must be presented to the Public Authorities and forwarded to the Insurance Company within seven days after the end of the exhibition. Failure to meet this deadline may result in losing the right to be indemnified. The Insurance Company will also handle claims and settlements at the end of the exhibition.

In any case, the Exhibitor undertakes to include in the supplementary insurance cover a clause in which the Insurance Company waives all recourse to action against the Exhibitors and BolognaFiere S.p.A., and in default he shall indemnify them from any action that may be brought against them.

Having taken note of the above, the Exhibitor (on his own account and that of his agents, employees or assistants) in any case expressly relieves BolognaFiere S.p.A. from any liability for loss or damage which for any reason should occur in the exhibition area assigned to him, during the exhibition or during installation or dismantling, and in respect of anything located therein, and accepts liability for any damage caused to third parties by the management of the exhibition space or by anything introduced therein and which is not covered in the terms or manner indicated above or by additional insurance cover taken out by the Exhibitor himself. BolognaFiere S.p.A. will accept no liability for consequential damages, damage to image, loss of revenues, etc. As regards direct damages, the Exhibitor accepts that the liability of BolognaFiere S.p.A. shall be limited to the insurance cover limits as stated above.

The Exhibitor accepts these limits of liability.

3) STAND FURNISHINGS AND PROHIBITIONS

3.A - DEFINITION OF TYPE OF STAND SET-UP AND APPROVAL PROCEDURE

Stand set-up, regardless of the area, is classified as follow:

- STANDARD set-ups
- NON-STANDARD set-ups

NON-STANDARD set-ups entails even just one of the following features:

- latticed metal ("American") structures with clear structural span exceeding 8.00 metres or with total length exceeding 32.00 metres
- horizontal metal or non-metal structures with clear span exceeding 4.50 metres
- installations anchored to BolognaFiere S.p.A. structures
- loft with space on upper level, even if not accessible to the public
- platforms higher than 80 cm

Booths with height exceeding 3,50 m will need a special authorization.

Also all structures placed in external areas with a surface area bigger than 75 sqm are to be considered as non-standard furnishings.

As the Exhibition Centre has obtained authorisation for use of the exhibition spaces based on a traditional set-up scheme, i.e., with parameters defined as STANDARD, an Exhibitor who proposes a set-up with even one of the above-mentioned characteristics must transmit (by fax or certified email) the design for the off-standard set-up, with signature and seal of a qualified engineer/architect, to BolognaFiere S.p.A. for approval, **no later than 10 September 2021.**

If the Exhibitor is not in possession of the design for the off-standard set-up signed by a qualified engineer/architect, the Exhibitor may, using the appropriate form available on the web portal www.befair.eu, request BolognaFiere S.p.A. to conduct an advance check of the design.

If the signed and sealed design for the off-standard structure(s) is not transmitted to BolognaFiere S.p.A., an inspection and validation will automatically be conducted and the Exhibitor will be charged twice the regular cost for such service specified on the above-mentioned forms.

Under all circumstances, BolognaFiere S.p.A. reserves the right to prohibit the assembly of off-standard set-ups that have not been approved in advance.

A static test made only by BolognaFiere S.p.A. is compulsory to build up non standard booths.

The exhibitor will pay for the test the amount indicated in the appropriate form on the web portal www.befair.eu.

In all cases, the construction of complex latticed metal ("American") structures (total length exceeding 32 metres, calculating both vertical and horizontal structures, and/or with clear structural span exceeding 8 metres) or horizontal metal or non-metal structures with clear span exceeding 4.50 metres, as well as intermediate floors, is subject to the transmission (by fax or certified email) to BolognaFiere S.p.A. of the structure's design, signed by the qualified engineer/architect, inclusive of a calculation report specifying load conditions during assembly and disassembly based on the construction method involved, as well as a certificate of correct assembly (at the end of work) carried out by a qualified technician.

In any case, BolognaFiere S.p.A. has always the right to examine stand projects that fall outside conventional set-ups in terms of dimensions and potential danger. The Exhibitor must provide technical drawings and the names of the technicians responsible for the structural and the furnishing parts, for aspects regarding health and safety at the workplace and for the equipment. The same obligation is also valid for stands built in external areas.

BolognaFiere S.p.A. may request the intervention of the Supervisory Committee for places of public entertainment.

3.B - STAND FURNISHING

The Exhibitor shall limit his display to the area allocated to him, as marked off by partition walls, painted lines or adhesive tape; on the front of the stands where there are no other reference elements, the display area shall not exceed the theoretical plane passing through the axis of the plates at the foot of the front pillars which support the side walls of the stands.

Inside the halls the stands may not exceed a standard height of 2,50 metres.

In order to consider any added thickness due to raised floors, lighting elements and light supports, including lattice structures, a maximum tolerance of a further 0,50 metres will be allowed, taking the above-specified limit to 3,00 metres, on condition that the structures whose sides watch over adjacent stands are perfectly finished and painted in a neutral, solid colour.

Stand fittings must not damage the aesthetic and visibility of nearby stands, in particular, in case of island stands (with four open sides) and peninsula stands (with three open sides), closing of more than 50% of the side of a stand will not be permitted to ensure the mutual visibility to the stands around them. Also stand fittings with perimeter walls higher than 3,00 metres will not be accepted. All 2-sided graphics must be positioned at a minimum distance of 2,00 metres from the boundaries of the adjacent stands.

BolognaFiere can verify all the above requirements and reserves the right to ask exhibitors to modify fittings and installations that do not comply with the provisions previously stated.

As to large exhibition areas that include passageways, indicated in the hall floorplan, no perimeter walls may obstruct these aisles.

Since unfurnished booths have no partition walls (but are just bare surface) every exhibiting company must directly erect walls between them and their neighbouring exhibitors, at its own expenses. Stand fittings must also include floor carpet and furniture.

Suspended piles and the related suspension systems, must be realised in accordance with the indications from the Ministry of the Interior (letter dated 01/04/2011) providing, in addition to the main connection system (belt, chain, auction...), also a safety connection (i.e. tension rod, band, rope, chain, anti-fall extensible systems).

For "suspended loads" we mean truss structures (simple type or "ring" type) or other types of beams or facilities and all related piles (monitors, projectors, lights, speakers and other sub-structures...) that are bound to a top or bottom structure or via a lifting element. All the above must be carried out in accordance and in possession of all the documents included in the said Ministry of the Interior communication.

Suspensions can be realised only in Halls 14-15-16-18-19-28-29-30-36-37. The suspension points must be carried out only by BolognaFiere who will also test them. Any request must be sent to BolognaFiere's Technical Office. Ground anchorage to floor and structures are prohibited in all the Exhibition Centre. Every Exhibitor is required to install at its stand, in a clearly visible way, fire-extinguishers as supplied by BolognaFiere S.p.A.

Glass walls in direct contact with the public must of the type set by law and following UNI standards.

In halls 14, 15, 16, 18, 21, 22, 25, 26, 28, 33 and 34 and partially in halls 29, 30, 37 double ceilings are permitted only if they are made from grill-type or perforated panels to allow the proper use of the sprinkler fire-fighting system and of the air-conditioning system.

All liability for the stability of the furnishings and the compliance of the furnishing materials with the fire prevention regulations currently in force shall be solely at the Exhibitor's charge, who expressly relieves BolognaFiere S.p.A. of any liability for any damage that may result from design and construction defaults, including the dimensioning drawn from the detailed plans of the areas occupied.

Any job that entails changes in the actual state of BolognaFiere's S.p.A. fixed and movable property (reinforcements, modifications, excavations, holes in fixtures, walls, structures and floor columns) may only be carried out with the prior written authorisation of BolognaFiere S.p.A., and shall be done at the expense and under the responsibility of the participant. This responsibility shall remain under the Exhibitor for the entire duration of the Exhibition until the stand is handed back to BolognaFiere S.p.A. Before beginning works the participant is required to pay to BolognaFiere S.p.A. an amount equal to the cost required to restore the stand to its original state, which will be undertaken by BolognaFiere S.p.A.

3.C - WASTE DISPOSAL

Set-up and dismantling periods:

It is strictly forbidden to all Stand fitters/Exhibitors to leave waste materials and/or special wastes in the exhibiting areas and in the boundary areas of the Fairgrounds, during all phases of the Exhibition.

Waste materials resulting from setting up and dismantling are under the Exhibitor's or his suppliers' liability.

Aisles of the halls will have to be kept cleared from any kind of waste or obstructing material.

The disposal of all waste materials and debris is at the Exhibitor and/or his representatives expense.

The proper implementation of the above-mentioned provisions will be checked by qualified BolognaFiere staff (attending every hall) during opening times.

In case of abnormalities, these will be recorded and put at the attention of the internal appointed authorities.

The non-compliance will result in a penalty for the Exhibitor as a refund to the necessary costs incurred by BolognaFiere for waste disposal for a total minimum amount of € 300,00 plus VAT for every 16sqm of the exhibiting area.

Exhibition

Waste produced during the exhibition must be delivered to the waste separation and recycling areas in the Exhibition Centre and separated by type

(paper, glass, metal, plastic, and undifferentiated).

3.D - PROHIBITIONS

It is specifically prohibited for Exhibitors to:

- apply loads to the structures of the halls, the walls, lighting pillars, etc.;
- attach to or suspend from the above-mentioned elements posters, cables, panels, banners, stickers;
- fix to the floor carpeting or similar material using highly adhesive double-sided tape, tape with internal paper support or tape of weak consistency;
- damage the equipment belonging to BolognaFiere S.p.A. and the structures of the halls;
- using the iron lift trucks, mobile cranes, aerial platforms, etc.
- leave waste materials and/or waste of any kind;
- stage or conduct any show or entertainment, of whatever kind, nature or characteristics, even if said show or entertainment is limited to the interior of the stand or designed for the presentation of products, without the prior authorization of BolognaFiere. It is the sole responsibility of the Exhibitor to obtain any authorization from the public health and safety authorities, and, in general, from the authorities responsible for the above initiatives, if and when required;
- enter the Exhibition Center, during the period of opening to the public, of vehicles apart from cars.

The Exhibitor accepts sole civil and criminal liability for damage caused by the non-observance or breach of the rules in force and of all the requirements set out in these Regulations and in the Safety File; the Exhibitor shall also hold harmless BolognaFiere S.p.A. in respect of any claims for compensation filed by third parties.

The Exhibitor shall notify his personnel and the firms operating on his behalf in the Exhibition Centre of the requirements and prohibitions as set out in these Regulations and in the Safety File, and also of the general rules of participation in the Exhibition.

In the event of non-observance of these rules and the relevant provisions set out in the Regulations regarding participation, BolognaFiere S.p.A. may take action against any firm defaulting (for example on the fire-prevention rules). Said actions may entail, in the event that supplementary measures to the general safety rules are adopted, the charging of the relative costs, estimated at not less than € 300.00/exhibition module, or an order requiring the partial or total disassembly of the stand and a declaration that the stand is unfit for use.

4) GENERAL SERVICES AND TECHNICAL SERVICES

Using their own appliances, BolognaFiere can supply to all booths electrical energy, water and compressed air as well as can connect booths to the telephone and data networks.

4.A - EXHIBITORS' SERVICES ASSISTANCE

Exhibitors may obtain all the necessary technical information on the general services within the Fairgrounds by applying to the Show Office of BolognaFiere.

For any of the services listed below, a new BolognaFiere e-commerce channel is now available to allow Exhibitors to order them directly in an easy and fast way on the website: www.befair.eu

- VIDEO EQUIPMENT RENTAL
- AUDIO EQUIPMENT RENTAL
- PLANTS AND FLOWERS RENTAL
- ELECTRICAL SYSTEMS
- WATER SYSTEMS
- COMPRESSED AIR
- STAND CLEANING
- CATERING
- HANDLING OF GOODS / PORTERAGE - FORWARDING AGENT
- TELEPHONE LINES and WI-FI

Please note the following:

The transport, loading and unloading of goods and portage services inside the Exhibition Centre is organized solely by BolognaFiere Forwarding Agent. Exhibitors wishing to bring goods of foreign origin into the Exhibition Centre

- to be displayed as samples - will be required to inform BolognaFiere writing to: customs@marconiffm.it

The following facilities are also available inside the Exhibition Centre:

- à la carte restaurants, self services, bars
- on request, cocktail breaks and delivery of refreshments to the stand.
- travel agency
- ironmongery
- insurance company

4.B - RESPONSIBILITY FOR SERVICES

BolognaFiere S.p.A. regulates but does not supply directly such services and therefore disclaims any and all responsibilities in respect of the performance thereof. Any complaint must be forwarded in written directly to the e-mail: vendite@bolognafiere.it

5) SPECIAL SERVICES

5.A - ENTRANCE PASSES FOR EXHIBITORS AND PARKING PERMIT FOR CARS

Exhibitors will be provided, free of charge, with entrance passes in the following quantities:

- N°2 Exhibitor's passes for stands up to 16 sqm
- N° 4 Exhibitor's passes for stands up to 32 sqm
- N° 6 Exhibitor's passes for stands up to 48 sqm
- N° 7 Exhibitor's passes for stands up to 64 sqm
- N°8 Exhibitor's passes for stands up to 96 sqm
- N°10 Exhibitor's passes for stands over 96 sqm

The Exhibitor will also be issued 1 car parking permit, regardless of the stand area. This sticker will entitle the Exhibitor to park the car in the designated areas indicated by BolognaFiere until spaces are available.

The Exhibitor shall be responsible for the correct use of these documents and the behaviour of those who use them.

These entrance passes and parking permit will be distributed only to companies that have settled all the invoices for the booths rental, before the opening of the Fair.

5.B - CATALOGUE

The catalogue (on line and/or printed) will include the data provided by the Exhibitors up to 45 days prior to the start of the Exhibition and - with regard to the name - the data supplied on the application form will be considered valid. As to the products, Exhibitors will have to fill in the appropriate form included in the reserved area, whose data will be automatically charged at the end of the filling out operation.

5.C - HOTEL RESERVATIONS SERVICE

A hotel reservation service is provided by the official supplier of BolognaFiere S.p.A., whom Exhibitors may apply to directly using the relevant form which sets out the conditions and rates or asking for a quotation by e-mail. The travel agency involved in this service is BolognaWelcome - (email: agenzia@bolognawelcome.it).

This service is also regulated but not organized by BolognaFiere S.p.A. which hereby disclaims all liability in respect thereof.

Any claims should be addressed in writing directly to the supplier and a copy should be sent to BolognaFiere S.p.A. for their information.

5.D - SOUND BROADCASTS, PAYMENT OF ROYALTIES

Exhibitors are not generally allowed to broadcast music or to use music and sound reproduction equipment. Any exceptions may be authorized in writing. Such authorization may be withdrawn at any time with immediate effect by means of written notice.

Authorization does not release the Exhibitor from the obligation to use the equipment in such a way as not to disturb the other exhibitors and visitors, with particular attention to noise pollution laws (maximum limited permitted by law) and nor does it relieve him from the obligation to abide, at his own expense, by copyright laws in force.

In order to fulfil all the necessary procedures, exhibitors may apply directly to S.I.A.E., Via Orfeo 33/a, 40124 - Bologna, tel. 051-4290311 - Fax 051-307280 - email: bologna@siae.it

5.E - ACTIVITIES IN THE STANDS

Exhibitors must at all times refrain from using common areas outside the boundaries of their stands for display or promotional activities. The Organiser has the right to remove all items from common areas and/or charge for the additional space used.

Failure to adhere to this guideline may result in the closure of the booth.

6) SPECIAL PROVISIONS

6.A - ENTRY WITH BAGS OR SUITCASES

BolognaFiere S.p.A. has the right to deny entry to the Exhibition Centre and to halls to people carrying bags, suitcases or other boxes which need to be placed in the cloakroom.

6.B - ENTRY WITH DOGS OR OTHER ANIMALS

Only dogs on a leash and wearing a muzzle or in a dog carrier can be admitted to the Exhibition Centre, except for dogs specifically trained to assist disabled persons that can access without restrictions.

6.C - BAN ON PHOTOGRAPHY AND FILMING AND ENTRY TO THE EXHIBITION CENTRE WITH PHOTOGRAPHIC AND FILMING EQUIPMENT

It is forbidden to enter the Exhibition Centre with cameras, film cameras, video recorders or any other type of filming equipment without the prior authorisation of BolognaFiere S.p.A. It is forbidden to photograph and film the interior of the Exhibition Centre, the stands and the goods on display without the prior authorisation of BolognaFiere S.p.A. and of the stand owner.

6.D - WIRELESS EQUIPMENT

Anyone who intends to use wireless equipment (such as two way radios, radio microphones, radio cameras etc.) are obliged to use equipment that comply with the EU standards (EU directive 99/05 - CE trademark) and get proper authorization (Electronic Communication Code, Article 107, paragraph 10 of the legislative decree 259/2003), if necessary and operate on permitted radio bands. For the fulfilment of the necessary procedures, interested parties may refer to the website of the Emilia Romagna Inspectorate of the Ministry for Economic Development (<http://www.ispettoratoemiliaromagna.altervista.org/index.php/aree-tematiche/apparati-di-debole-potenza>).

7) RIGHT OF CONTROL AND FACULTY OF INTERVENTION BY BOLOGNAFIERE S.P.A.

BolognaFiere S.p.A. takes steps to ensure that the regulations and the general conditions for participation are observed and all those entering the Exhibition Centre are obliged to abide by the provisions and instructions that BolognaFiere S.p.A. sets at the entrance and inside the Venue; these instructions may take the form of signs, written notices and loudspeaker announcements and may also be issued by the service personnel or by any other means; it should be noted that loud-speaker announcements and instructions given by the service staff will prevail over any other form of communication.

Exhibitors are reminded that failure to observe the rules or the violation of prohibitions may result in the immediate closure of the stand by officers or agents of BolognaFiere S.p.A. or in the withdrawal of the entry passes and parking sticker and also this will not entitle the Exhibitor to any refund whatsoever.

8) MODIFICATIONS TO THESE REGULATIONS

Any possible provisions of law or norms that should modify the terms of these Exhibition Regulations will be immediately and automatically effective, even though the printed Exhibition Regulations document has not been modified or changed to reflect the said amendments.

Moreover BolognaFiere S.p.A. has the right to adopt at any time any measures as are deemed appropriate, which the exhibitor shall immediately observe and apply, with regard to fire prevention, work safety and security, accident and damage prevention, and the safety of exhibitors and visitors, particularly referring to the Anticovid Norms as to the entrance of Exhibitors and Stand Builders in the Bologna Exhibition Centre (encl. 2 of the Exhibition Centre Regulations).

These latter provisions may be brought to the attention of Exhibitors by any means and they shall prevail over the general provisions in force up to that time.